

Chart of Cable Cords for PCs

These Chart became effective on April 1, 2020.

Please refer to the "Guide on How to Use Portable PC Batteries" for more instructions.

CONTENTS

ACER JAPAN1	EVEREX2	KOUZIRO4	SHARP7
APPLE1	FUJITSU2	MITSUBISHI4	SONY7
CASIO1	HITACHI3	Mous computer ...5	SOTEC8
COMPAQ2	IBM4	NEC5	TOSHIBA8
DELL2	IIYAMA4	NTT DoCoMo6	VICTOR9
EPSON2	KOHJINSHA4	Panasonic6	

ACER JAPAN

PC Name	Type	Plug Code
Travel Mate	331 T	B1
Aspire	7745G, 5745G, 5741, 3820T, one753	B2

APPLE

PC Name	Type	Plug Code
Macintosh	PowerBook 1400c-series, PowerBook 2400c-series, PowerBook 3400c-series PowerBook G3-series, PowerBook (FireWire) series PowerBook Duo 230, Duo 270, Duo 280, Duo 2300 iBook 300, 366, 466 (first generation model only)	B5
Macintosh	PowerBook G4-series, iBook series (from Dual USB onwards) (not including MacBook series. Some foreign models are not compatible.)	B7

CASIO

PC Name	Type	Plug Code
CASSIOPEIA FIVA	MPC101M31, MPC103-M625, MPCM32	B6

COMPAQ

PC Name	Type	Plug Code
E	P700/10X/192/20/C/P2	B4
Presario	1245, 1200XL(S12XL123), 1400(14XL343, 14XL344, 14XL346) 1600, 1600XL(S16XL143, S16XL146, S16XL257, S16XL258) 1700(17XL367, 17XL368)	B2

DELL

PC Name	Type	Plug Code
Inspiron	2500, 3700, 3800, 4000, 5000, 5000e, 7500, 8000	B8
Latitude	C-series (C400, C510, C600, C610, C800, C810) CP-series, CPi-series (300ST, 300XT, 366XT, A400XT) CPt-series , CPx-series (H500GT), CS-series, CSx-series V710, V740	B8

EPSON

PC Name	Type	Plug Code
Endeavor	TK-300	A3

EVEREX

PC Name	Type	Plug Code
Step Note	VA4100J, VA4300J	B2

FUJITSU

PC Name	Type	Plug Code
BIBLO	MG50E/A, MG50L, MG70L	B6
BIBLO	LCE50, MG30, MG50S, MG50T, MG50T/V, MG50U, MG50UV, MG50X, MG50Y, MG55RT, MG70H, MG70J, MG70M, MG70R, MG70RT, MG70ST, MG75J, MG75Y, MGG70, NB15B, NB15BT, NB40R, NB40S, NB50G, NB50H, NB50HY, NB50JY, NB50L, NB50M, NB50R, NB50S, NB50T, NB55G, NB55GT, NB55H, NB55H/T, NB55J, NB55JT, NB55L, NB55LT, NB55M, NB55R, NB55RT, NB55RTS, NB55S, NB55ST, NB55T/T, NB60LW, NB70G, NB70S, NB75G, NB75GT, NB75H, NB75H/T, NB75L, NB75LT, NB75M, NB75RT, NB75ST, NB90LW, NF40T, NF40U, NF40UV, NF40X, NF45T, NF50U, NF50W/V, NF50XB, NF50XW, NFG40, NFG70, NWWG90, RE70, RS18D, RS55E, RSG, AH(700/5B, 550/5B, 570/5BM, 550/3BT, 530/3B, 530/1B, 52, 77, 56, 54, 42), EH30, DH(77, 54), NH(900/5BD, 77)LH(700/3B, 520/3B), SH(760/3B, 560/3B, 76, 54), PH(770/3B, 540/1A, 520/1A, 50, 74), MH(380/1A, 30), FH(99, 98, 77, 56, 54, 30)	B8

FUJITSU

PC Name	Type	Plug Code
BIBLO	MC(2/40, 2/400X, VII23, VIII23, IX23) MF(2/40, 2/400X, 5/55D, 5/600R, 5/600W, IX26) MG(8/75, 8/800, 9/85C, 9/850, 10A, 12D, 50J) NA, NB(9/90R, 9/95, 9/95L, 9/1000, 9/1000L, 9/1130H, 9/1130M) NC(13D, III13, III16, VI20, VI20D, VII20) NE(33, 33E, 36L, 36L1, 36L3, 36LA, 36X, 331, 2/40, 2/43L, 2/43LR, 2/45 2/450L, 2/450LR, 3/45L, 3/45W3, 4/50D3, 4/60R3, 4/600R 5/55RK, 5/60C, 5/60D, 5/600R, 5/650D, 5/650R, 5/800HR 6/60C, 6/65R, 6/650R, 6/750R, 6/850HB VII20, VII20D, VII23, VII23D, VII23X, IX26, IX26X) NJ(4/45D,5/50R,5/55C,5/60R) NL, NP(III16, V16, V16D, V20, VII23) NR(IX26X, IX30L, VI30L), NS(IX26X, VIII23X) NU(III13, III13D, III16, V16, V16D, V16X, VI23, VI23D, VII23) 5100-series, 5200-series	A1
BIBLO LOOX	LS80B, LS80BW, P70, Q70, S5/53, S5/53W, S8/70, S8/70W S73AW, T5, T5/53W, T5/533, T55, T60, T70, T75, T8, T86AW, T9, U50X	A1
BIBLO LOOX U	U50X/V	B6
Pen Centra	130 (Win CE Version)	A1
LIFEBOOK	270LS, 273LS, 610MG, 612MG, 613MG, 645, 650, 655, 660, 665, 670MC, 675MG 680MC, 780MT, 820MG, 820MT, 830MG, 830MT 6100MG, 6500MF, 6500NU, 6600MF, 6600NU, 6650MR, 6650NU, 6700MF9, 6700NU9 6750MR, 6750NA, 6800MG, 6850NA, 7090MT, 7130MG B8200, B8220, B8400, P8210, P8240, Q8230, Q8240, S8200, S8300, U8240	A1
LIFEBOOK	610NU, 612NU, 665NU, 685NU, 686NU, 715NU, 716NU, 718NU, 820MG, 820NA, 830MG, 6113NA, 6120NA, 6120NU, 6650NA, 6750NA, 6866NU, 7140MR, 7160NU, 7170NU, 7515NU, A8230, A8270, A8280, C8200, C8210, C8220, C8250, E8110, E8210, E8300, S8125, S8205, S8220, S8225, S8305, T8210, T8220	B2

HITACHI

PC Name	Type	Plug Code
FLORA Prius	200C5TMP*1 ¹	B2
FLORA Prius Note	210, 220, 250, NS1	A3
FLORA Prius Note	20R (2TC, 4TC, 4TD, 4TR)	B4
Prius Air	100F	B2
Prius Gear	150H2LMC, 150H2LVCT	B4
Prius note	20L, 20M	B1
Prius note	200E, PN31K4T, PN33K, PN33K1S, PN33M, PN37K1S	B2

*1 Cannot be used for models with built-in nickel hydrogen batteries.

IBM

PC Name	Type	Plug Code
ThinkPad	i-1459	B1
ThinkPad	235, 240, 380, 385, 390, 535, 560, 570, 600, 600E, 700E, 700ED, T20 240Z (2609-71J, 2609-72J, 2609-81J, 2609-82J), A20p, A21e, A30, A31P R32, R40e, R50p, R52, S30, T20, T23, T30, T43, X20, X41, TransNote	A3
ThinkPad i-series	1157, 1200 (1161-41J, 1161-71J, 1161-234, 1161-264), 1800, 2000 (1161-234)	A3

IYYAMA

PC Name	Type	Plug Code
AVENUE	MPX710 (NT310K)	B2

KOHJINSHA

PC Name	Type	Plug Code
SA	1F Series, 5-series	B2

KOUZIRO

PC Name	Type	Plug Code
FRONTIER	FRBB11/B, FRN413, FRNC131WF, FRNH700/Q, FRNV11, FRNW5301	B2

MITSUBISHI

PC Name	Type	Plug Code
AMITY	CN, GP, SP, VP	A5
Apricot	AL300	B2

Mous computer

PC Name	Type	Plug Code
m-Book	T, D, G, P, F, B, M	B2

NEC

PC Name	Type	Plug Code
LaVie C	LC (50H/34DA1, 60H/54DR, 500J/34DR, 600J/54DC, 600J/54DR, 700J/54DR,800J/54ER)	A3
LaVie F	LF750/7D	B2
LaVie J	LJ300A2, LJ700/7, LJ5002D, LJ (5003E, 5004D, 7003F, 7004F)	B2
LaVie L	LL (350AD, 370HD, 370/K, 500/6D, 500AD, 550WG, 530WH, 700/7D, 700FD, 700GD, 700GD1Y, 750/7D, 750FD, 770FG, 790FD, 900/7D, 900FD, 950/7D, 3004F, 5003D, 5004D, 5009D, 5504D, 7003D, 7004D, 7004DW, 7503D, 7509D, 9009D, 870CS, 750CS, 770FS, 750FS)	B2
LaVie Light	PCBL33, BL (550CS, 350CS, 350FW)	B2
LaVie M	LM500/7D, LM600J52DB, LM600J52DC, LM700/7E, LM5001D, LM5002D, LM5003E, LM7001D	A2
LaVie M	LM (40H32D1, 50H52DC, 50H62DC, 500J32D2)	A5
LaVie M	LM700J62DH	B6
LaVie M	LM (350V, 750FS, 550FS)	B2
LaVie MX	LX (60T5, 60T/51EC, 60T6S1EC)	A5
LaVie N	LN3009DW	A2
LaVie NX	LA500, LT (23, 30D/5, 34A, 44A)	A2
LaVie NX	LB20/30A, LB20/40A	A1
LaVie NX	LB26C	B1
LaVie NX	LB30C	B4
LaVie NX	LB (33H, 400)	A5
LaVie NX	LW (23, 30, 33, 36H, 40H, 46H, 450)	B2
LaVie RX	LR300/8D, LR500/9D, LR500/AD, LR700/8E	A2
LaVie S	LS (50H/34DV, 50H/34DV2, 50H/34DW, 50H/34DW2, 55H/54DV, 55H/54DW 65H64DH, 600J/55DV, 800J/56DH, 7009D, 550CS, 350CS, 150CS, 550FS, 350FS, 170HS, 150FS, 200FS)	B2

NEC

PC Name	Type	Plug Code
LaVie T	LT5002D	A1
LaVie U	LU (45L3SB, 50L54DC, 700R63DC, 700R63DR, 700R64DV)	B2
LaVie Z	LZ3001A	A5
mobio	MB12, MB20	A1
VersaPro	VA26D	A3
VersaPro	VA (50J, 60J), VA85J/AF, VJ16HB, 17FLX, 22AF, 22M, VY20M, 25	A5
VersaPro	VA80	A1
VersaPro	VJ14MFD2, VJ16MFD3 VA70RS, 80CH, 86H, 90JWX, 93JBH VJ20DF, 20DG, 20RF, 20Wf, 22S, 22X, 80BH, 80BW, 80M VY16T, 16XF, 17ED, 20DF, 20F, 22S, 22X, 80BH, 80BW, 80M	B2
VersaPro R	VA18XR XUJ	B2

NTT DoCoMo

PC Name	Type	Plug Code
Mobile Pack III	Libretto M3	A4

Panasonic

PC Name	Type	Plug Code
Let's note	AL-N1, AL-N2, CF-02, CF-S21/51V, L1 (GA, XA, XR, XS)	A1
Let's note / Let's note LIGHT	CF-R3, CF-R4, CF-R5, CF-R6, CF-R7, CF-T4, CF-T7, CF-W2, CF-W4, CF-W5, CF-W7, CF-W8, CF-Y4, CF-Y7, CF-S10, CF-B10, CF-N10U, CF-J10T	A3
Let's note ace	AL-N3, CF-A44-EJ8, CF-A77	A1
Let's note mini	AL-N4, CF-M32	A1
Let's note comm	CF-A1R, CF-A1V, CF-C33, CF-L1A, CFL1-XS, CF-M1R, CF-M1V, CF- M32J8	A1
Let's note LIGHT	CF-R1PCAXR	A1
Let's note HITO	CF-A2 (4H2), CF-B5 (ER), CF-M2 (C, EV, R, XR), CF-S (23J8S), CF-X1 (D, R, W)	B6
CF-G1	CF-G1	A2

Panasonic

PC Name	Type	Plug Code
PRONOTE	CF-11, CF-B5, CF-L1, CF-M2	A1
PRONOTE FG	CF-M34	B6

SHARP

PC Name	Type	Plug Code
Copernicus	RW-A230	A5
Mebius	MJ700M, MJ710R, MN-390-X26, MN-450-H23, PC-MW50J, PC-MW70J	A3
Mebius	CB1- (C7, M1, M3, M5, R3S), MJ (700M, 700R, 710R), PC-AE30L, PC-AE50L, PC-AE50M PC-CH40N, PC-CH40S, PC-CL1-5CA, PC-CL50G, PC-CS30J, PC-CS50J, PC-CS50N PC-CS50S, PC-CW50W, PC-CW60, PC-FS1, PC-GP1, PC-GP2, PC-MC1- (3CA, 3CC) PC-MC30, PC-MC30F, PC-MP5BG7, PC-MP40H, PC-MP50G, PC-MP70G, PC-MR40J PC-MR50H, PC-MR80H, PC-MV1- (5CA, VC1, VC4), PC-RJ9, PC-RJ900V, PC-SX1 PC-WA50K, PC-WA70K, PC-WA80, PC-WE40S, PC-WE50S, PC-WT50W, PC-WZ50W	B2
Mebius	PC-BJ100M, PC-FJ (40, 100R, 100V), PC-PJ (120H, 120S, 140H, 140S)	B1
Mebius	CB-MT1- (H1, H1S, H3, H3R, H3S, H5, HT5R) PC-MM (25NE, 50F), PC-MM1- (H1W, H3E, H4E, H6W) PC-MM2-5NE, PC-MT2- (F1, S3), PC-PJ1, PJ2, PJ2-S2	A5
Mebius	PC-AL50F, PC-AL50FY, PC-AL70F, PC-XV70F	A2
Mebius	MN-395-C33	A1
Telios	HC-AJ1, AJ2, AJ3	A5
Telios / Mebius	HC-VJ1C, VJ2C, PJ-FJ (20, 30, 120C, 120M, 140M, 140R, 160M)	B4

SONY

PC Name	Type	Plug Code
VAIO	PCG-777BP PCG-881, 881/BP, 883, 885, 887, 887/BP2, 888 PCG-F (23/BP, 26/BP, 60/BP, 66/BPK), PCG-FX (77S/BP, 77V/BP, 99V/BP) PCG-R505 (F/BD, FR, FR/D, J/BD) PCG-XR (1E/BP, 7E/K, 9E/K, 100E/K) PCG-Z505 (D, DX, F, FX, G/BP, GR/K, J/BP, JL, JX, NR)	B3 *2

SONY

PC Name	Type	Plug Code
VAIO	PCG-777BP PCG-881, 881/BP, 883, 885, 887, 887/BP2, 888 PCG-F (23/BP, 26/BP, 60/BP, 66/BPK), PCG-FX (77S/BP, 77V/BP, 99V/BP) PCG-R505 (F/BD, FR, FR/D, J/BD) PCG-XR (1E/BP, 7E/K, 9E/K, 100E/K) PCG-Z505 (D, DX, F, FX, G/BP, GR/K, J/BP, JL, JX, NR)	B3*2 ¹
VAIO	PCG-505EX, 505EX/64, 505G, 505GX, 505GX/4G, 505X, 505X/64 PCG-505R, 505RS, 505RX, 505S, 505SX, 505V, 505V/CBX PCG-C1MR/BP, C1MR/X, C1MSX, C1MZX, C1R, C1S PCG-GR3F/BP, GR5F/BP, GR9/K, GRS, GT1 PCG-SR1/BP, SR1C/BP, SR1M/BP, SR9/GK, SR9/K, SR9C/K PCG-SRX3/BD, SRX3F, SRX7E/P PCG-TR1B, TR1P, TR2B, TR2E, TR3/B, TR3E/B PCG-U1, U3, V505B, V505E/B, V505F/B, VX7/BD, VX9/P PCG-VGNT51BL, VGNT71BL, VGNT71BT, Z1/P, Z1R/P VGN-G1KAP, G1LAP, TT53, TX52B/B, TX72B/B, U50, UX70, UX71, UX90, UX91, VPC(F139FJ, F138FJ, EB39FJ, EB-38FJ, EB37FJ, EB36FJ, Z139FJ, S139FJ, Y219FJ, M129AJ, F229FJ) VPC(F238FJ, F237FJ, F236FJ, CB38FJ, EH29FJ, EH28FJ, EH-26FJ, EL25FJ, EG24FJ, SE19FJ, SB39) VPC(SB38, Z219FJ, YB39KJ)	B6

SOTEC

PC Name	Type	Plug Code
Afina	AG353	B2
e-note	645t	A3
e-note	M270 (TRX3), M380 (TRX4)	B2
WinBook	Trim	A5
WinBook	WL2120, WS334B, WA5514PB	B2

TOSHIBA

PC Name	Type	Plug Code
DynaBook PX	PX100	B1
Dynabook	DB45K/DC8, DB47K/2CA, DB47K/4CA, DB47K/4RA, DB55C/4CA, DB55C/4DA, DB60C/4RA, PABX51, PACX45, PAEX55, PATV64, PATX66, PAUX23KNU,T851/D8, T751/T8, D731 (T9, T7, T5), D711/T3, T551 (T6, T4), T451 (59, 57, 46, 35, 34), R731 (38, 37, 36, 10), R631/28, N300/02, PN3000	B2
Dynabook	PX-DB45KDC8	A3

*2 Some VAIO models, in which the AC adapter has a power voltage of 19 to 19.5V, may not be compatible with Battery B when the battery is fully charged. This will not damage your computer, but we recommend not using the battery.

Do not use A1 cables with these computers. This may cause damage to your computer.

TOSHIBA

PC Name	Type	Plug Code
Dynabook	A1 *3, V1 *3, R10170L7	A2
Dynabook C8-series	21DCMEN *3	A2
Dynabook C9-series	212/PDEW *3, 212/PMEW *3	A2
Dynabook CX-series	1212CDEW, 1212CMEW, 1214LDEW, 2213CMSW, 3214CDSW	A2
Dynabook CX-series	45ELR, CX825LL	B2
Dynabook M-series	PAM3260CRE ¹ *3, PAM3275PRH *3	A2
Dynabook PORTEGE	300CT, 7010CT, 7200, SS6000, SS7000, SS7020X *3, SS7020X2 *3	A2
Dynabook Satellite	305, 310, 315, 320, 325, 2050, 2060, 2100K40/SCA, 2140 *3, 2270 *3, 2510, 2550S, 2550X, 2650, 4000X, 4010X, 4030, 4050X, 4240, 4380 *3, 4600 *3, Pro440	A2
Dynabook SS	DB50CDC8 *3, DB55C2CM *3, DB60P4RA *3, DB60P4RA2 *3, DB65P4RA DB65P4RC *3, DB65P/4MC *3, DB70P/5MC *3, DS65C4RC *3, MX370LS *3, PAMX25A PAS4275PNHW *3, PAS5280PNKW *3, PAS5280PNLN PASX190NK *3, PASX190NR *3	A2
Dynabook SS	3330 to 3490 *3, S1 *3	A4
Dynabook SS PORTEGE	3000 to 3300 *3	A4
Dynabook SS (PX)	DB55C4DA, DS50C/1CA, DS50C/1CCR, DS50C/1DAJ	A2
Dynabook TX-series	PATX2513CMSW *3	A2
Dynabook VX-series	PAVX2W15LDSW *3	A2
Dynabook TECRA	530, 730, 8000 *3, 8100 *3	A2
Dynabook V-series	PAV4493PMHW	A2
Libretto	50, 60, 70, L1 *3, L2 *3, L5 *3, LS *3	A2
Libretto	100 *3, ff1050 *3, ff1100 *3, ff1100V *3, SS1000 *3, SS1010 *3	A4
QOSMIO	E10370LS, E10375LS	A2
QOSMIO	T750/T8A, T560/T4A, T560/58A, T550/D8A, T350, R730	B2

VICTOR

PC Name	Type	Plug Code
InterLink	MP-C303-A	A5

*3 The models may not be compatible with Battery A when the battery is fully charged. It will not damage your computer, but we do not recommend using the battery.